

Place
finger in number
to be dialled.
880
Pull round to stop
and release

Place
finger in number
to be dialled.
881
Pull round to stop
and release

Place
finger in number
to be dialled.
882
Pull round to stop
and release

Place
finger in number
to be dialled.
883
Pull round to stop
and release

Place
finger in number
to be dialled.
884
Pull round to stop
and release

Place
finger in number
to be dialled.
885
Pull round to stop
and release

Place
finger in number
to be dialled.
884-5
Pull round to stop
and release

Place
finger in number
to be dialled.
886
Pull round to stop
and release

Place
finger in number
to be dialled.
887
Pull round to stop
and release

Place
finger in number
to be dialled.
888
Pull round to stop
and release

Place
finger in number
to be dialled.
889
Pull round to stop
and release

Place
finger in number
to be dialled.
890
Pull round to stop
and release

Place
finger in number
to be dialled.
891
Pull round to stop
and release

Place
finger in number
to be dialled.
892
Pull round to stop
and release

Place
finger in number
to be dialled.
893
Pull round to stop
and release

Place
finger in number
to be dialled.
894
Pull round to stop
and release

Place
finger in number
to be dialled.
895
Pull round to stop
and release

Place
finger in number
to be dialled.
896
Pull round to stop
and release

Place
finger in number
to be dialled.
897
Pull round to stop
and release

Place
finger in number
to be dialled.
898
Pull round to stop
and release

**Norchard 884
Extension 23**

**Norchard 884
Extension 24**

Norchard 800 Series Dial Labels		
DFR tn001c		
ISSUE C	14/11/2013	Renumbered etc
ISSUE B	18/11/2012	850 added
ISSUE A	31/03/2006	Opening Issue
Dean Forest Railway		
		